

U Mototechny 107 251 62 Tehovec Czech Republic

Tel.: +420 323605511 +420 323660013 Fax: +420 323607922 http://www.skybergtech.com

E-mail: info@skybergtech.com

SET for solar power stations SKY46FOGSIT

Description:

The set for the solar power stations consists of a DC input radio-frequency interference suppression filter, sinusoidal filter, choke and line radio-frequency interference suppression filter. In case of synchronous operation of the inverters is possible to add a three-phase sinusoidal filter consisting of three single-phase chokes.




TECHNICAL PARAMETERS:


Nominal operating voltage Un: 3x230/400Vac Extent of operating currents
Extent of operating temperature : 0°C + 40°C In: 46A


Туре	Nominal current	Nominal voltage	Weight	Conductor cross section	basic dimensions [mm]					
	[A]		[kg]	[mm 2]	length	height	width	pitch	pitch	other
SKY3FL50B	50	3x230/400Vac	1,1	6 - 10	160	56	98	88	83	5x6
SKY3TL50-0,6	50	3x230/400Vac	9	6 - 10	180	156	147	122	86	7x13
SKY3FSM48-400	48	3x230/400Vac	22	lug 35x8	240	240	220	200	121	9x15
SKY1FLDC50C	50	1200Vdc	3,5	20x3	357	61,5	176	302	114	9x16

^{*} After a deal there is a possibility of modification of the filter construction according to the customer's request.


Dimensional drawing:







SKY1FLDC50C



Attenuation characteristics:






Diagram:

LY LINE LOAD L3'


SKY3FSM48-400



SKY1FLDC50C



Principle diagram:



Dimensioning, wiring:

The DC interference suppression filter is supposed to be wired between the solar panels and converter. A low-frequency LCL filter, which consists of the sinusoidal filter and output choke, is supposed to be wired to the output side of the converter. The LC sinusoidal filter creates sinusoidal voltage from PWM converter. The L choke reduces inrush currents between the solar power station and LV line. The radio-frequency interference suppression filter, which reduces size of radio-frequency interference to distribution system from the converter, is supposed to be wired behind the output low-frequency LCL filter.